

Change What Appears Under More on the SMART Board

SMART Board step-by-step guide

Before you begin: These instructions use the SMART Board controls shown in Wolf Creek classrooms. Menu placement may vary slightly after a software update.

STEP 1 Open the SMART Board toolbar

Tap the arrow tab on the right edge of the screen to open the floating toolbar.

Click more and select from there.



Open the SMART Board toolbar.

STEP 2 Select More


Tap More to see the additional tools available on the SMART Board.



Select More.

STEP 3 Find the tool you need

Review the icons in the More panel and tap the tool you want to open.



Find the tool you need.

STEP 4 Close the panel

Tap More again, or tap away from the panel, when you are finished.



Close the panel.

Finished

The SMART Board is ready to use. If the control does not respond as shown, restart SMART services or submit a Freshdesk request.